



LED teach-in

1. LED device turned off
2. press ON button on the remote (if OFF)
3. press channel button and  simultaneously >3 sec.
4. red LED flashes
5. turn LED device on

*LED flashing stops,
radio remote control ready.*


HEATING teach-in

1. heating device turned off
2. press ON button on the remote (if OFF)
3. press channel button and  simultaneously >3 sec.
4. red LED flashes
5. turn heating device on

*LED flashing stops,
radio remote control ready.*


application

1. press ON button on the remote (if OFF)
2. choose channel
3. choose function for light or heating




Attention! The remote changes over to stand-by after a little while, to save battery. The wake up works with the channel button.

LED EINLERNEN

1. LED-Gerät ausgeschaltet
2. ON Taste betätigen (wenn Handsender OFF)
3. Kanaltaste und gleichzeitig Taste  betätigen >3 sek.
4. rote LED blinkt
5. LED-Gerät einschalten

*LED blinken erlischt,
Funkfernbedienung betriebsbereit.*


HEIZUNG EINLERNEN

1. Heizgerät ausgeschaltet
2. ON Taste betätigen (wenn Handsender OFF)
3. Kanaltaste und gleichzeitig Taste  betätigen >3 sek.
4. rote LED blinkt
5. Heizgerät einschalten

*LED blinken erlischt,
Funkfernbedienung betriebsbereit.*

Verwendung

1. ON Taste betätigen (wenn Handsender OFF)
2. Kanal wählen
3. Funktion Licht oder Heizung wählen



Achtung der Handsender schaltet nach einer kurzen Zeit auf Standby um die Batterien zu schonen. Das Aufwecken erfolgt über die Kanaltaste.